



RS485 Splitter

VFD-CMD 04/08 Instruction Sheet


To complete the communication function of VFD inverter and DVP PLC, Delta produces multi-machine communication board by itself. RS-232 communication port of PC connects to the input terminal of this multi-machine board via RS-232/RS485 converter. An inverter can connect to multiple inverters by using this communication board (1 to 4 to 8) to control multi-machine communication. The diagram is shown as following:




VFD-CMD04



VFD-CMD08



PC → PLC → multi-machine communication board → inverter



PC → converter → multi-machine communication board → inverter

